

PREPARATION FOR INSTALLATION

Before the board is actually installed into your computer:

1. Locate the various sockets, jumper option points and other parts of the board to facilitate subsequent connections and installation.
2. Based on the hard disk you are going to use, refer to the charts shown to determine the proper jumper configuration for your particular hardware.
3. Attach and route the connecting cables to your hard disk.

JUMPER CONFIGURATION

1. The hard disk controller board can be tailored to perform with several different external hard disk units. The first hard disk unit that you use is called Drive C. If you have Drive C already, then your second unit will be called Drive D.
2. Both Drive C and Drive D are, in actuality, secondary hard disk units. However, in the case of Drive C, a secondary unit is being used as a primary hard disk.
3. Before you install this controller card, be sure that if this installation is for your secondary hard disk, Drive D, that you have had the disk internally configured to perform as Drive D by your nearest Radio Shack Service facility.
4. To adjust the board to work properly with your particular hard disk, there is a strip of 4 pairs of pins which protrude above the surface of the board, which can be connected into the circuit, a pair at a time, by means of a jumper. A jumper is a small, black plastic block which is placed over a pair of pins and connects them together. For the purpose of this board, a jumper is said to be either ON or OFF the board.
5. Find the brand and model of the hard disk you have. Type 1 is a Tandy 35 Megabyte secondary hard disk, 250-4172. Type 3 is a Tandy 15 Megabyte secondary hard disk, 250-4156. Having determined the TYPE number, if this drive is to be Drive C. If this is your second hard disk, Drive D.
6. Find the type number and look across the chart to determine which of the jumpers is to be ON or OFF. If the jumper is to be ON then place a black, plastic block over the pair of pins indicated and press the jumper downwards, firmly, until it is seated. If the jumper number is shown as OFF, leave the pair of pins uncovered.

(css/jej-05/11/94)

□