

NOTE: If you have the Sony MPF420-1 Floppy Drive, the jumper settings, (there is no slide switch) are as follows:

Jumper pins 15-10 for DS1 (default)

Jumper pins 10-5 for DS0

The other two jumpers should be left as is, on the jumper block.

#### SETTING THE DRIVE DESIGNATION SWITCH

The drive is originally configured to be used as the second diskette drive in the system. If you do not want to use it as the second diskette drive, select the appropriate switch setting. The drive designation switch is located on the back of the drive next to the 34-pin connector. See the following table.

The following table summarizes the switch settings:

Switch Setting	Function
0	Indicates that the drive is the first or only diskette drive in the system.
1 *	Indicates that the drive is the second diskette drive in the system.
2	Indicates that the drive is the third diskette drive in the system. Some computers do not support three drives. See your computer user's guide for more information.
* This is the factory default setting.	