

# Shark.

Motorized Brush | Brosse motorisée | Cepillo motorizado

## Recommended Use

This accessory picks up pet hair, loose debris, and powerfully deep cleans dander out of upholstery and surfaces. The rotating plate allows for cleaning on both horizontal **(A)** and vertical **(B)** flat surfaces.

## Maintenance

To access the brushroll for cleaning, detach this accessory from the vacuum, turn it upside down and lift up the top bar above the brushroll **(C)**. Close when finished cleaning.

## Mode d'emploi recommandé

Cet accessoire permet le poil d'animaux, les débris et nettoie en profondeur et avec puissance, pour retirer les phanères des meubles et surfaces. Le suceur rotatif permet de nettoyer les surfaces horizontales **(A)** et verticales **(B)**.

## Entretien

Pour nettoyer la brosse rotative, détachez l'accessoire de l'aspirateur. Ensuite, mettez l'accessoire à l'envers et soulevez la barre supérieure au-dessus de la brosse rotative **(C)**. Refermez l'accessoire une fois le nettoyage terminé.

## Uso recomendado

Este accesorio recoge pelo de mascotas, restos sueltos y limpia profundamente la caspa del tapizado y las superficies. La placa rotativa permite limpiar tanto superficies planas horizontales **(A)** como verticales **(B)**.

## Mantenimiento

Para acceder al cepillo cilíndrico para limpiarlo, desconecte el accesorio de la aspiradora, déle vuelta y levante la barra sobre el cepillo cilíndrico **(C)**. Cíerrela cuando termine de limpiarlo.

