```
                ┌─────────────────────────────────┐
                │   ┌─────────────────────────┐   │
                │   │                         │   │
                │   │                         │   │
                │   │                         │   │
                │   │                         │   │
                │   │                         │   │          ┌── Power Indicator
                │   └─────────────────────────┘   │   ┌──────┤
                │    Tandy VGM-390        ■  ┌───┐<┤────────── Power ON/OFF Button
                │                            └───┘ │
                ├─────────────────────────────────┤
                │   ■ ■  ■ ■  ■ ■  ■ ■    ■ ■  ■ ■ │
                └───┬───┬────┬────┬───────┬────┬───┘
          H-Size ───┘   │    │    │       │    │
             H-Center ──┘    │    │       │    └── Brightness
                 V-Size ─────┘    │       └── Contrast
                    V-Center ─────┘
```

Contrast and Brightness:

Adjust the contrast and brightness controls to suit the room's lighting and
your viewing preferences.

CAUTION: If the same characters or graphics are shown for a long period of
         time with the contrast and brightness controls set to their
         maximum positions, part of the screen might be damaged. Use these
         controls
         with care.

Horizontal Position:

Adjust the control to horizontally position the display. Turn H-POSI
clockwise to move the display to the right or counterclockwise to move it
to the left.

Vertical Position:

Adjust this control to vertically position the display. turn V-POSI
clockwise to move the display up or counter clockwise to move it down.

Horizontal Size:

Use this control to adjust eh display's width. Turn H-SIZE clockwise to
widen the display or counterclockwise to narrow it.

Vertical Size:

Use this control to adjust the display's vertical size. Turn V-SIZE
clockwise to increase the display's vertical size or counterclockwise to
decrease it.

Power ON/OFF:

To turn on the VGM-390, press POWER. The POWER indicator lights. Press
POWER again to turn off the monitor.

(rjs/jej-09/27/94)