

Dear Customer

◆ About the Upgrade of the DC-GH5 Firmware

The following functions were added or changed from Ver. 2.2 of the firmware.

Please read this in conjunction with the owner's manual for the camera.

- The firmware version can be checked from the [Version Disp.] of the [Setup] menu.

[Lens Fn Button Setting] has been added to the [Custom] menu.

Sets the function to be assigned to the focus button of an interchangeable lens.

- You can call up the assigned function by setting the focus selector switch of a compatible interchangeable lens to [Fn] and then pressing the focus button of the lens.

MENU →  [Custom] →  [Lens / Others] →
[Lens Fn Button Setting]

Settings: [Focus Stop]/[AF/AE LOCK]/[AF-ON]/[Stabilizer]/
[Focus Area Set]/[AF Mode/MF]/[Preview]/[Off]/
[Restore to Default]

- When [Focus Stop] is used, the focus is locked while the focus button is pressed and held.