

## **ZOOM H and F-Series Multi Track ASIO Driver**

### **Installation Guide (Windows)**

Copyright(C) 2015 ZOOM Corporation. All Rights Reserved.

Ver. 2.0.0

● **Zoom Corporation does not bear liability for any damages or third-party claims arising from the use of the software, whether directly or indirectly. Unauthorized redistribution, sale, leasing, renting, alteration, or reverse engineering of the software is prohibited. Features and specifications of the software and the contents of the documentation may be changed in future without notice.**

The actual content of screens and messages on the computer may differ from the illustrations used in this manual.

## <Contents>

Introduction.....	3
Operation Environment Requirements .....	3
Precautions .....	3
Updating the driver .....	4
Installation .....	5
Uninstallation .....	11

## Introduction

Thank you for downloading the ZOOM H and F-Series Multi Track Driver.  
This document describes how to install and uninstall the driver.

## Operation Environment Requirements

**Operating system:** Windows® 7 later (32bit / 64bit) / Windows® 8 later (32bit / 64bit)

### **Precautions**

- 1) Start installation and uninstallation disconnecting the product from PC.**
- 2) Before starting this application, shut down all other applications that are running.**

## Updating the driver

If a ZOOM H-Series Multi Track Driver is already installed, first uninstall the old driver.  
Then install the new driver.

## Installation

1. Start Windows without any USB devices including the product (Except keyboard and mouse).
2. Shut down any applications that are running.
3. Double-click on the "H\_and\_F-Series\_Multi\_Track\_ASIO32.exe" icon or "H\_and\_F-Series\_Multi\_Track\_ASIO64.exe" icon depending on the operating system you use.



32bit




64bit

4. Select language and click [OK].




5. To start the installation, click [Next].



6. The License Agreement is displayed. Read the agreement and place a check mark in the “I accept the terms in the License Agreement” box to confirm your acceptance of the agreement. Then click [Next].



7. To start the installation, click [Install].




When a warning message “Windows security” appears, click [Install].





8. Click [Finish] to finish installation of InstallShield.



9. Next, connect the product to the computer using a USB cable.

- H5 : Select [AUDIO INTERFACE] from USB menu and select [MULTI TRACK].
- H6 : Select [Audio Interface] from USB menu and select [Multi Track].
- F8 : Select [Audio Interface] from USB menu and select [Multi Track (PC/Mac)].

When the product is connected to Computer, “Installing device driver software” will launch and it finish automatically.



## Uninstallation

1. Start Windows without any USB devices including the product (Except keyboard and mouse).
2. Shut down any applications that are running.
3. Click on the Start→Programs→ZOOM→H and F Series Multi Track Driver→ " Uninstall H and F Series Multi Track Driver " icon.



4. The uninstallation process starts. Confirm that you want to proceed by clicking [YES]. To cancel the process, click [NO].



\*The uninstallation is completed automatically.