

## RESULT CODES

Number (V0)	Word (V1)	Description
0	OK	The command line was successfully processed.
1	CONNECT	The Carrier signal has been detected.
2	RING	The phone is ringing. RING only indicates that the phone is ringing. The modem does not answer it unless commanded to or unless auto-answer is enabled.
3	NO CARRIER	Carrier was not detected or was lost. NO CARRIER is displayed if the carrier signal from the other modem is not detected for a sufficient length of time. NO CARRIER means that a data call was not successfully completed.
4	ERROR	There was an error in the command line.
5	CONNECT 1200	Carrier has been detected at 1200 bps.
6	NO DIALTONE	No dial tone has been detected by the modem during the dial sequence. This result code will only appear if X2, X4 or the W command have been selected.
7	BUSY	The modem has detected a busy signal. This result code will only appear if the X3, X4 or @ commands have been selected.
8	NO ANSWER	The number dialed was not answered. This result code will only appear if the @ command has been used in dialing.

## RESULT CODE NOTES

- \* The NO ANSWER result codes appears only when the modem is dialed using the @ command.
- \* V0 and V1 are the modem commands that determine whether the modem is to render numeric or verbal result codes, respectively.
- \* The Q command determines whether or not results are sent. In the default state, the modem returns only Codes 0-4.
- \* RING only indicates that the phone is ringing. The modem does not answer it unless commanded to or unless auto-answer is enabled.
- \* NO CARRIER is displayed if the carrier signal from the other modem is not detected for a sufficient length of time. NO CARRIER means that a data call was not successfully completed.

\* CONNECT 1200, NO DIAL TONE and BUSY codes are displayed only when the extended result code set is enabled.

(dkh-07/28/93)