



1. Insertion slot for tape cartridge.
2. TRACK shows the position of the read write heads on tape.
3. READ and WRITE indicators show the operating mode of read/write head.
4. FORWARD and REVERSE indicators show the direction of tape movement.
5. SELECTED indicator lights when tape drive is operating.
6. POWER indicator lights when TCS-100 AC power is on.
7. ON/OFF switch turns on power to tape drive when in Position 1, turns off power when in Position 0.
8. Fuse holder compartment.
9. POWER CORD receptacle.
10. TAPE CABLE connector.

(dkh-08/04/93)

□