

BYTESAVER

ASSEMBLY MANUAL

BYTESAVER ASSEMBLY INSTRUCTIONS

The Cromemco BytesaverTM kit can be assembled in about one evening. All components are mounted on the component side of the pc board (the side with the printed legend) and soldered on the opposite side. Be sure to use high-quality rosin core solder for the assembly and a fine-tipped low wattage soldering iron.

() Solder in position the 10 14-pin IC sockets, the 6 16-pin IC sockets, and 8 24-pin IC sockets.

() Solder in position the $\frac{1}{4}$ watt resistors:

| | | |
|---------|------|----------------------|
| R1 | 47K | yellow-violet-orange |
| R2 | 10K | brown-black-orange |
| R3 | 180 | brown-gray-brown |
| R4 | 1K | brown-black-red |
| R5 | 9.1K | white-brown-red |
| R6 | 1.5K | brown-green-red |
| R7 | 1K | brown-black-red |
| R8 | 47 | yellow-violet-black |
| R9 | 1K | brown-black-red |
| R10 | 10 | brown-black-black |
| R11 | 5.6K | green-blue-red |
| R12 | 5.6K | green-blue-red |
| R13 | 10K | brown-black-orange |
| R14 | 5.6K | green-blue-red |
| R15 | 180 | brown-gray-brown |
| R16-R39 | 18K | brown-gray-orange |

() Next install the 1N914 diodes. NOTE we recommend that no diode be installed in the diode position just below transistor Q0. When using the Bytesaver we recommend that the PROM containing the Bytemover software be inserted in PROM position zero. By not installing this diode there will be no chance of accidentally programming this PROM.


When installing the diodes be careful to orient them properly, noting the position of the cathode (banded) end. Due to the close spacing of the holes in the pc board, the diodes should be mounted on end.

() Now install the 23 capacitors as shown on the pc board. Be careful that the electrolytic capacitors are oriented with the positive (+) end as shown.

() Now solder the transistors in place taking care to orient them properly. Note that Q8 and Q9 are 2N3906 transistors, and Q10 is a type MPS6560. All other transistors are type 2N3904.

() Install the pc board switch, SW1, in the upper left corner of the board.

- () Install the Cromemco high-speed pulse transformer, model XT8K, in position T1. Note that the leads are asymmetrically positioned so that there is only one correct orientation of the transformer.
- () Now install IC14, the positive twelve volt regulator IC, using a 6-32 X $\frac{1}{4}$ screw and nut.
- () Next install the heatsink in the upper right corner of the board just starting the nuts on the 6-32 x $\frac{3}{8}$ screws. Install IC12 and IC 13 being sure to place the insulating washer between IC13 and the heat sink. The nylon screw must be used to hold IC13 in place. (The insulating washer supplied may have to be trimmed with a pair of scissors to clear the protrusions of the heatsink.) Tighten the nuts on the screws in the heatsink assembly only after all screws have been inserted. Take care that the leads on the voltage regulators do not come in contact with sides of the openings in the heatsink.
- () Next install three jumper wires to select where the Bytesaver is to reside in memory space. Each of the three high order address lines (A15, A14, and A13) may be tied either to the corresponding "H" or "L" terminal. For the Bytesaver to reside in the top 8K of memory space, for example, the three jumper wires would be installed as shown:






- () Now install the ICs in their sockets being careful to orient pin one of each IC as shown by the small white dot on the pc board at each IC position. Install a PROM containing Bytemover software in PROM position 0.

The assembly of your Bytesaver is now complete. Detailed operating instructions are given in the Bytemover software manual.

PROM AVAILABILITY: Additional 2704 and 2708 PROMs are available from Cromemco. The 2704 is \$50 each, and the 2708 is \$75. Our PROMs are factory fresh, full speed devices that we purchase directly from the manufacturer.

WAIT STATE: Should you wish to use low speed 2704 or 2708 PROMs in your Bytesaver (with access times greater than 450 ns) there is a provision for a wait state. Simply insert a jumper wire, as shown, between IC10 and IC11. No jumper wire need be inserted here when using full-speed PROMs.

REPAIR: If for any reason you need service on your Bytesaver, you may return it to Cromemco along with a check for \$35. The \$35 covers the cost of repair and return postage. We reserve the right to not repair any Bytesaver that we judge to be unserviceable.



BYTEMOVER

SOFTWARE FOR THE CROMEMCO BYTESAVER



Cromemco

Specialists in computer peripherals

2432 Charleston Rd., Mountain View, CA 94043 • (415) 964-7400

CROMEMCO BYTEMOVER 3.1 OPERATING INSTRUCTIONS

Cromemco BYTEMOVER software is designed to be used with the Cromemco 8K BYTESAVER. When you purchase a Bytesaver with one 2704 PROM, the Bytemover software comes preprogrammed in the 2704 PROM.

The 2704 PROM containing the Bytemover software is normally inserted into PROM location 0 on the Bytesaver board. The Bytemover software can be used to program a PROM in any of the PROM locations on the Bytesaver board. The Bytemover software can also be used to transfer programs from PROM to RAM. The operation of the Bytemover software is controlled by the setting of the front panel sense switches on the Altair computer. To use the Bytemover software there must be a RAM board in the Altair beginning at location zero in memory; further, this RAM board must be unprotected for proper execution of the Bytemover software.

STEP-BY-STEP INSTRUCTIONS

- 1) Before using the Bytesaver you must install three jumper wires to set the location of the Bytesaver in memory space. This is shown in Figure 1. The assembled Bytesaver comes with A13, A14, and A15 each tied to the corresponding "Hi" pad to position the board at the very top of memory. In the following instructions it is assumed that this is the jumper connection used.
- 2) With the Altair 8800 power turned off, plug the Bytesaver board into the computer.
- 3) Be sure that the program power on the Bytesaver is turned OFF (program power switch in the down position.)
- 4) Turn on the Altair. Raise the reset switch, then raise the stop switch, and then raise the reset switch once again to initialize the Altair.
- 5) Raise address switches A15, A14, and A13. All other address switches should be down.
- 6) Raise the examine switch. You are now examining the contents of the first byte of PROM in PROM location zero of the Bytesaver memory board (memory location 340 000). If the PROM supplied with your Bytesaver is in this PROM location the data lights will read "061", the first byte of the Bytemover program.

EXAMPLE: Transfer the Bytemover program from PROM to RAM beginning at location zero in RAM.

- 1) Raise the reset switch.
- 2) Depress the unprotect switch (on the Altair front panel).
- 3) Raise A15, A14, and A13. Raise the examine switch. The data lights should read "061" octal.

4) Now set the sense switches for the task to be done, referring to Fig. 2.

| | |
|------------|--|
| A15 - Down | to transfer from PROM to RAM |
| A14 - Down | for the transfer of 1K bytes. |
| A13 - Down | All down since we are transferring from the same PROM that contains BYTEMOVER (PROM 0) |
| A12 - Down | |
| A11 - Down | |
| A10 - Down | |
| A9 - Down | All down for storage to begin at location zero in RAM. |
| A8 - Down | |

5) Push the run switch. In less than one second the contents of PROM will be transferred to RAM. (Of course the contents of the PROM are unaffected by this operation.)

6) Raise the STOP switch.

7) Raise the reset switch. Note that the data lights read "061".

EXAMPLE: Program a 2708 PROM inserted in PROM location 1. This PROM is to be programmed with the contents of the first 1K bytes of RAM beginning at location zero in memory. The Bytemover software is still in the PROM in PROM location zero on the Bytesaver board.

1) Raise the reset switch.

2) Depress the unprotect switch (on the Altair front panel)

3) Raise A15, A14, and A13. Raise the examine switch. The data lights should read "061" octal.

4) Raise the protect switch on the Bytesaver board (i.e. program power switch to the ON position). The protect light on the Altair front panel should go off when this switch is raised.

5) Now set the sense switches for the task to be done:

| | |
|------------|--|
| A15 - Up | to program a PROM |
| A14 - Down | (always down for PROM programming) |
| A13 - Down | To select the PROM 1K higher in memory than the PROM that contains BYTEMOVER |
| A12 - Down | |
| A11 - Up | |
| A10 - Down | All down for transfer to begin at location zero in RAM. |
| A9 - Down | |
| A8 - Down | |

6) Push the RUN switch. Note that panel light A9 is blinking at a rate of about twice per second. When this light stops blinking the PROM programming is complete.

7) Raise the STOP switch.

8) Now note the INTE light on the Altair front panel. If this light is on, the BYTEMOVER VERIFIER has verified that the contents of the programmed PROM are indeed identical to the contents of the selected 1K bytes of RAM. If this light is off, the PROM has not programmed correctly; this could be due, for example, to a defective PROM.

EXAMPLE: Altair 8K BASIC can be stored in seven 2708 PROMs. Given that these seven PROMs are in PROM locations 1 through 7 on the BYTESAVER board, 8K BASIC can easily be transferred into RAM using the following procedure:

- 1) Raise the RESET switch.
- 2) Depress the unprotect switch (on the Altair front panel).
- 3) Raise A15, A14, and A13. Raise the examine switch. The data lights should read "061" octal.
- 4) Now set the sense switches for the task to be done:
 - A15 - Down to transfer from PROM to RAM.
 - A14 - Up for a 7K transfer
 - A13 - Down
 - A12 - Down
 - A11 - Up
 - A10 - Down
 - A9 - Down
 - A8 - Down

} To begin transfer from the PROM 1K higher
} in memory than the BYTEMOVER program.

} All down for storage to begin at location
} zero in RAM.
- 5) Push the RUN switch. In less than one second BASIC will be loaded into RAM (it sure beats paper tape!). Raise the STOP switch.

EXAMPLE: If you do not have BYTEMOVER in PROM, you can program a PROM with BYTEMOVER that is stored in RAM. The BYTEMOVER software (a listing of which is attached) must first be loaded into RAM beginning at location zero in memory. The BYTEMOVER software can then be burned into a PROM using the following procedure:

- 1) Raise the reset switch.
- 2) Depress the unprotect switch (on the Altair front panel).
- 3) Insert an erased PROM into PROM location 0 on the BYTESAVER board.
- 4) Examine location 000 240 in memory.
- 5) Raise the program power switch on the BYTESAVER board.
- 6) Set the sense switches with A15 and A14 and A13 up.
- 7) Push the RUN switch. When light A9 stops blinking the programming is complete. The INTE light will be on to verify correct programming.
- 8) Turn off PROM program power by depressing the switch on the BYTESAVER.

ERASING PROMs: The 2704 and 2708 PROMs are erased by shining intense UV light through their quartz window. One such UV source, the UV-85 PROM ERASER, is available for \$37.50 from the BYTE SHOP, 1063 El Camino Real, Mountain View, CA 94040.




Fig. 1. How to set the Bytesaver address in memory. The built Bytesaver comes with A15, A14, and A13 connected to the corresponding "Hi" terminals so that memory address occurs when these three bits are high. Any or all of these address lines may be connected to the corresponding "Lo" terminal to move the memory board lower in memory. There are thus eight positions in memory that this board can be used.





FIGURE 2. FUNCTION OF THE SENSE SWITCHES IN THE BYTEMOVER PROGRAM.

Fig. 3. Bytesaver physical layout.



BYTEMOVER ASSEMBLY LANGUAGE LISTING

| | | |
|------|----------|--|
| 0000 | | 0000 * BYTEMOVER (T. M.) SOFTWARE FOR |
| 0000 | | 0001 * CROMEMCO 8K BYTESAVER (T. M.) |
| 0000 | | 0002 * VERSION 3.1 |
| 0000 | | 0003 * SELF-RELOCATING SOFTWARE LOCATABLE AT ANY |
| 0000 | | 0004 * 1024 BYTE (1K) BOUNDARY IN MEMORY |
| 0000 | | 0009 * ROUTINE TO FIND ONESELF IN MEMORY |
| 0000 | | 0010 SP EQU 6 |
| 0000 | | 0019 * DEFINE FIRST 4 BYTES IN MEMORY AS STACK |
| 0000 | 31 00 00 | 0020 LXI SP, 0 |
| 0003 | | 0029 * SAVE FIRST FOUR BYTES IN REGISTERS |
| 0003 | C1 | 0030 POP B |
| 0004 | D1 | 0040 POP D |
| 0005 | | 0049 * REPLACE BYTE 0 WITH A 'RETURN' |
| 0005 | 2E C9 | 0050 MVI L, 0C9H |
| 0007 | F3 | 0051 DI |
| 0008 | E5 | 0060 PUSH H |
| 0009 | E5 | 0070 PUSH H |
| 000A | 00 | 0080 NOP |
| 000B | 00 | 0081 NOP |
| 000C | 00 | 0082 NOP |
| 000D | 31 04 00 | 0090 LXI SP, 4 |
| 0010 | CD 00 00 | 0100 CALL 0 |
| 0013 | | 0101 * ROM LOCATION NOW IN BYTE 3 |
| 0013 | 31 02 00 | 0110 LXI SP, 2 |
| 0016 | E1 | 0120 POP H |
| 0017 | | 0129 * RETURN BYTES 0-3 |
| 0017 | 31 04 00 | 0130 LXI SP, 4 |
| 001A | D5 | 0140 PUSH D |
| 001B | C5 | 0150 PUSH B |
| 001C | | 0159 * STORE ROM LOCATION IN SP |
| 001C | F9 | 0160 SPHL |
| 001D | 0E 00 | 0170 MVI C, 0 |
| 001F | 59 | 0180 MOV E, C |
| 0020 | 69 | 0190 MOV L, C |
| 0021 | | 0199 * INPUT SENSE SW COMMANDS |
| 0021 | DB FF | → 0200 IN 255 |
| 0023 | 57 | 0210 MOV D, A |
| 0024 | | 0219 * STRIP RAM ADDRESS |
| 0024 | E6 07 | 0220 ANI 7 |
| 0026 | 07 | 0230 RLC |
| 0027 | 07 | 0240 RLC |
| 0028 | | 0249 * STORE RAM ADDRESS IN BC |
| 0028 | 47 | 0250 MOV B, A |
| 0029 | 7A | 0260 MOV A, D |
| 002A | | 0269 * STRIP ROM ADDRESS |
| 002A | E6 38 | 0270 ANI 56 |
| 002C | 0F | 0280 RRC |
| 002D | 00 | 0290 NOP |
| 002E | 67 | 0300 MOV H, A |
| 002F | 39 | 0310 DAD SP |
| 0030 | 2E 00 | 0320 MVI L, 0 |
| 0032 | 7A | 0330 MOV A, D |
| 0033 | EB | 0340 XCHG |
| 0034 | | 0341 * ADDRESS OF ROM BEING PROCESSED IN DE |
| 0034 | | 0349 * BRANCH TO TRANSFER OR PROGRAM ROUTINE |

| | | | | | |
|------|----|-------|------|--------------------------------------|-----------------------------|
| 0034 | E6 | 80 | 0350 | ANI | 128 |
| 0036 | 0F | | 0360 | RRC | |
| 0037 | 0F | | 0370 | RRC | |
| 0038 | C6 | 2D | 0380 | ADI | 45 |
| 003A | 21 | 00 00 | 0390 | LXI | H, 0 |
| 003D | 6F | | 0400 | MOV | L, A |
| 003E | 39 | | 0410 | DAD | SP |
| 003F | E9 | | 0420 | PCHL | |
| 0040 | | | 0500 | * ROUTINE TO TRANSFER ROM TO RAM | |
| 0040 | F9 | | 0510 | SPHL | |
| 0041 | 21 | 0B 00 | 0520 | LXI | H, 11 |
| 0044 | 39 | | 0530 | DAD | SP |
| 0045 | EB | | 0550 | XCHG | |
| 0046 | F9 | | 0560 | SPHL | STACK CONTAINS ROM LOCATION |
| 0047 | EB | | 0570 | XCHG | H&L CONTAIN LOOP ADDRESS |
| 0048 | 11 | 00 00 | 0580 | LXI | D, 0 |
| 004B | | | 0588 | * START OF TRANSFER LOOP | |
| 004B | | | 0589 | * INCREMENT ROM ADDRESS | |
| 004B | 3B | | 0590 | DCX | SP |
| 004C | | | 0599 | * MOVE DATA FROM ROM TO RAM | |
| 004C | F1 | | 0600 | POP | 6 |
| 004D | 02 | | 0610 | STAX | B |
| 004E | | | 0619 | * INCREMENT RAM ADDRESS | |
| 004E | 03 | | 0620 | INX | B |
| 004F | | | 0629 | * INCREMENT BYTE COUNT | |
| 004F | 13 | | 0630 | INX | D |
| 0050 | 7A | | 0640 | MOV | A, D |
| 0051 | E6 | 04 | 0650 | ANI | 4 |
| 0053 | 07 | | 0660 | RLC | |
| 0054 | 07 | | 0670 | RLC | |
| 0055 | 00 | | 0680 | NOP | |
| 0056 | 85 | | 0690 | ADD | L |
| 0057 | 6F | | 0700 | MOV | L, A |
| 0058 | E9 | | 0710 | PCHL | |
| 0059 | 00 | | 0716 | NOP | |
| 005A | 00 | | 0717 | NOP | |
| 005B | | | 0719 | * JUMP TO 00B1 FROM TRANSFER ROUTINE | |
| 005B | 3E | 56 | 0720 | MVI | A, 56H |
| 005D | 85 | | 0725 | ADD | L |
| 005E | 6F | | 0730 | MOV | L, A |
| 005F | E9 | | 0740 | PCHL | |
| 0060 | | | 1000 | * ROUTINE TO PROGRAM ROM | |
| 0060 | 00 | | 1010 | NOP | |
| 0061 | | | 1019 | * MOVE RAM ADDRESS INTO HL | |
| 0061 | 69 | | 1020 | MOV | L, C ; ZERO |
| 0062 | 7C | | 1030 | MOV | A, H ; ZERO |
| 0063 | 60 | | 1040 | MOV | H, B ; ZERO |
| 0064 | | | 1049 | * MOVE RAM ADDRESS INTO SP | |
| 0064 | F9 | | 1050 | SPHL | ; ZERO |
| 0065 | 67 | | 1060 | MOV | H, A ; ZERO |
| 0066 | 2E | 6B | 1070 | MVI | L, 107 ; 6BH |
| 006B | | | 1079 | * INCREMENT RAM ADDRESS | |
| 006B | 01 | 00 00 | 1080 | LXI | B, 0 ; ZERO B & C |
| 006B | | | 1089 | * INCREMENT RAM ADDRESS | |
| 006B | 3B | | 1090 | DCX | SP |
| 006C | | | 1098 | * USE STAX AND POP 6 (PSW) | |
| 006C | | | 1099 | * TO MOVE DATA FROM ROM TO RAM | |

| | | | |
|------|----------|------|--|
| 006C | F1 | 1100 | POP 6 |
| 006D | 12 | 1110 | STAX D |
| 006E | | 1119 | * INCREMENT ROM ADDRESS |
| 006E | 13 | 1120 | INX D |
| 006F | | 1129 | * INCREMENT BYTE COUNT |
| 006F | 03 | 1130 | INX B |
| 0070 | | 1138 | * B STORES TWO CONSTANTS |
| 0070 | | 1139 | * # COMPLETE PASSES & IN ROM CNT |
| 0070 | 7B | 1140 | MOV A, B |
| 0071 | | 1149 | * # PASSES = 32 ? |
| 0071 | FE FC | 1150 | CPI 252 |
| 0073 | 3F | 1160 | CMC |
| 0074 | 1F | 1170 | RAR |
| 0075 | 1F | 1180 | RAR |
| 0076 | | 1198 | * SET 64 TO 0 FOR TWO MINUTE TIMER VERSION |
| 0076 | E6 40 | 1200 | ANI 64 |
| 0078 | | 1201 | * A=64 IF COMPLETED 32 PASSES |
| 0078 | 2E 7D | 1205 | MVI L, 7DH |
| 007A | 85 | 1210 | ADD L |
| 007B | 6F | 1220 | MOV L, A |
| 007C | E9 | 1225 | PCHL |
| 007D | 2E 6B | 1226 | MVI L, 6BH |
| 007F | 7B | 1230 | MOV A, B |
| 0080 | E6 04 | 1240 | ANI 4 |
| 0082 | | 1241 | * A=4 IF END OF 1024 BYTE PASS |
| 0082 | 07 | 1250 | RLC |
| 0083 | 07 | 1260 | RLC |
| 0084 | 07 | 1270 | RLC |
| 0085 | 85 | 1280 | ADD L |
| 0086 | 6F | 1290 | MOV L, A |
| 0087 | | 1291 | * GO BACK TO 1090 UNLESS OVERFLOW |
| 0087 | | 1292 | * THEN GO TO 1380 FOR |
| 0087 | | 1293 | * ADDRESS SUBTRACTION |
| 0087 | | 1294 | * OR 2135 FOR QUIT |
| 0087 | E9 | 1300 | PCHL |
| 0088 | 00 | 1350 | NOP |
| 0089 | 00 | 1360 | NOP |
| 008A | 00 | 1370 | NOP |
| 008B | | 1378 | * ANOTHER PROGRAM PASS TO BE DONE |
| 008B | | 1379 | * ADJUST ROM AND RAM ADDRESSES |
| 008B | 7C | 1380 | MOV A, H |
| 008C | 21 00 FC | 1390 | LXI H, 64512 |
| 008F | | 1399 | * SUBTRACT 1024 FROM ROM ADDRESS |
| 008F | 39 | 1400 | DAD SP |
| 0090 | F9 | 1410 | SPHL |
| 0091 | 21 00 FC | 1420 | LXI H, 64512 |
| 0094 | | 1429 | * SUBTRACT 1024 FROM RAM ADDRESS |
| 0094 | 19 | 1430 | DAD D |
| 0095 | EB | 1440 | XCHG |
| 0096 | 67 | 1450 | MOV H, A |
| 0097 | 2E 6B | 1460 | MVI L, 107 |
| 0099 | 7B | 1470 | MOV A, B |
| 009A | E6 FB | 1480 | ANI 248 |
| 009C | | 1489 | * INCREMENT PASS COUNTER BY ONE |
| 009C | C6 0B | 1490 | ADI 8 |
| 009E | 47 | 1495 | MOV B, A |
| 009F | | 1499 | * GO BACK TO 1090 |

| | | | |
|------|----------|------|---------------------------------------|
| 009F | E9 | 1500 | PCHL |
| 00A0 | | 2000 | * ROUTINE TO LOAD BYEMOVER INTO ROM |
| 00A0 | DB FF | 2010 | IN 255 |
| 00A2 | 47 | 2020 | MOV B, A |
| 00A3 | E6 E0 | 2030 | ANI 22A |
| 00A5 | 1E 00 | 2040 | MVI E, 0 |
| 00A7 | 4B | 2050 | MOV C, E |
| 00AB | 57 | 2060 | MOV D, A |
| 00A9 | 7B | 2070 | MOV A, B |
| 00AA | E6 1F | 2080 | ANI 31 |
| 00AC | 47 | 2090 | MOV B, A |
| 00AD | 67 | 2100 | MOV H, A |
| 00AE | 2E 60 | 2110 | MVI L, 96 |
| 00B0 | E9 | 2120 | PCHL |
| 00B1 | | 2121 | * CHECK FOR 7K TRANSFER OF ROM TO RAM |
| 00B1 | C6 1A | 2122 | ADI 1AH |
| 00B3 | 6F | 2123 | MOV L, A |
| 00B4 | DB FF | 2124 | IN 255 |
| 00B6 | E6 40 | 2125 | ANI 64 |
| 00B8 | 0F | 2126 | RRC |
| 00B9 | 0F | 2127 | RRC |
| 00BA | 85 | 2128 | ADD L |
| 00BB | 6F | 2129 | MOV L, A |
| 00BC | E9 | 2130 | PCHL |
| 00BD | | 2133 | * PROGRAMMER VERIFICATION ROUTINE |
| 00BD | | 2134 | * PART 1 |
| 00BD | 7C | 2135 | MOV A, H |
| 00BE | 21 00 FC | 2145 | LXI H, 64512 |
| 00C1 | 39 | 2155 | DAD SP |
| 00C2 | F9 | 2165 | SPHL |
| 00C3 | 2E CD | 2175 | MVI L, OCDH |
| 00C5 | 67 | 2185 | MOV H, A |
| 00C6 | E9 | 2195 | PCHL |
| 00C7 | 00 | 2205 | NOP |
| 00C8 | 00 | 2210 | NOP |
| 00C9 | 00 | 2215 | NOP |
| 00CA | 00 | 2220 | NOP |
| 00CB | | 2229 | * ROM TO RAM TRANSFER STOP ROUTINE |
| 00CB | FB | 2230 | EI |
| 00CC | E9 | 2240 | PCHL |
| 00CD | | 2248 | * PROGRAMMER VERIFICATION ROUTINE |
| 00CD | | 2249 | * PART 2 |
| 00CD | 7C | 2250 | MOV A, H |
| 00CE | 21 00 FC | 2260 | LXI H, 64512 |
| 00D1 | 19 | 2270 | DAD D |
| 00D2 | EB | 2280 | XCHG |
| 00D3 | 2E F1 | 2290 | MVI L, 0F1H |
| 00D5 | 67 | 2300 | MOV H, A |
| 00D6 | 01 00 00 | 2310 | LXI B, 0 |
| 00D9 | E9 | 2320 | PCHL |
| 00DA | 00 | 2625 | NOP |
| 00DB | | 2629 | * 7K TRANSFER COMPLETION CHECK |
| 00DB | D6 90 | 2630 | SUI 90H |
| 00DD | 6F | 2640 | MOV L, A |
| 00DE | 7A | 2650 | MOV A, D |
| 00DF | C6 04 | 2660 | ADI 4 |
| 00E1 | 57 | 2670 | MOV D, A |

| | | | | | |
|------|----|----|------|-----------------------------------|------|
| 00E2 | FE | 38 | 2680 | CPI | 56 |
| 00E4 | 3F | | 2685 | CMC | |
| 00E5 | 3E | 00 | 2690 | MVI | A, 0 |
| 00E7 | 1F | | 2700 | RAR | |
| 00E8 | 85 | | 2710 | ADD | L |
| 00E9 | 6F | | 2720 | MOV | L, A |
| 00EA | E9 | | 2730 | PCHL | |
| 00EB | | | 2879 | * ROM PROGRAMMER STOP ROUTINE | |
| 00EB | 00 | | 2880 | NOP | |
| 00EC | 00 | | 2881 | NOP | |
| 00ED | FB | | 2885 | EI | |
| 00EE | E9 | | 2890 | PCHL | |
| 00EF | E9 | | 2900 | PCHL | |
| 00F0 | E9 | | 2906 | PCHL | |
| 00F1 | | | 2918 | * PROGRAMMER VERIFICATION ROUTINE | |
| 00F1 | | | 2919 | * PART 3 | |
| 00F1 | 3B | | 2920 | DCX | SP |
| 00F2 | F1 | | 2930 | POP | 6 |
| 00F3 | EB | | 2940 | XCHG | |
| 00F4 | | | 2949 | * COMPARE FOR GREATER | |
| 00F4 | BE | | 2950 | CMP | M |
| 00F5 | EB | | 2960 | XCHG | |
| 00F6 | 17 | | 2970 | RAL | |
| 00F7 | E6 | 01 | 3000 | ANI | 1 |
| 00F9 | 2F | | 3010 | CMA | |
| 00FA | 3C | | 3011 | INR | A |
| 00FB | 85 | | 3015 | ADD | L |
| 00FC | 6F | | 3020 | MOV | L, A |
| 00FD | 3B | | 3030 | DCX | SP |
| 00FE | 3B | | 3040 | DCX | SP |
| 00FF | | | 3050 | * COMPARE FOR LESSER | |
| 00FF | F1 | | 3055 | POP | 6 |
| 0100 | 2F | | 3056 | CMA | |
| 0101 | EB | | 3058 | XCHG | |
| 0102 | 86 | | 3059 | ADD | M |
| 0103 | EB | | 3060 | XCHG | |
| 0104 | C6 | 07 | 3061 | ADI | A, 1 |
| 0106 | 3F | | 3065 | CMC | |
| 0107 | 17 | | 3070 | RAL | |
| 0108 | E6 | 01 | 3090 | ANI | 1 |
| 010A | 2F | | 3100 | CMA | |
| 010B | 3C | | 3101 | INR | A |
| 010C | 85 | | 3105 | ADD | L |
| 010D | 6F | | 3110 | MOV | L, A |
| 010E | 03 | | 3130 | INX | B |
| 010F | 13 | | 3140 | INX | D |
| 0110 | 78 | | 3150 | MOV | A, B |
| 0111 | E6 | 04 | 3180 | ANI | 4 |
| 0113 | 2F | | 3190 | CMA | |
| 0114 | 3C | | 3191 | INR | A |
| 0115 | 85 | | 3195 | ADD | L |
| 0116 | 6F | | 3200 | MOV | L, A |
| 0117 | E9 | | 3210 | PCHL | |

BYTEMOVER VERSION 3.1 OCTAL LISTING

```
061 000 000 301 321 056 311 363 345 345 000 000 000 061 004 000
315 000 000 061 002 000 341 061 004 000 325 305 371 016 000 131
151 333 377 127 346 007 007 007 107 172 346 070 017 000 147 071
056 000 172 353 346 200 017 017 306 055 041 000 000 157 071 351
371 041 013 000 071 353 371 353 021 000 000 073 361 002 003 023
172 346 004 007 007 000 205 157 351 000 000 076 126 205 157 351
000 151 174 140 371 147 056 153 001 000 000 073 361 022 023 003
170 376 374 077 037 037 346 100 056 175 205 157 351 056 153 170
346 004 007 007 007 205 157 351 000 000 000 174 041 000 374 071
371 041 000 374 031 353 147 056 153 170 346 370 306 010 107 351
333 377 107 346 340 036 000 113 127 170 346 037 107 147 056 140
351 306 032 157 333 377 346 100 017 017 205 157 351 174 041 000
374 071 371 056 315 147 351 000 000 000 000 373 351 174 041 000
374 031 353 056 361 147 001 000 000 351 000 326 220 157 172 306
004 127 376 070 077 076 000 037 205 157 351 000 000 373 351 351
351 073 361 353 276 353 027 346 001 057 074 205 157 073 073 361
057 353 206 353 306 007 077 027 346 001 057 074 205 157 003 023
170 346 004 057 074 205 157 351 000 000 000 000 000 000 000 000
```