

Date & Time	Start up	Communications
Date [03/31/1992] Time [14:31:19]	Num Lock Light [ON ] CPU Speed [Fast] Shadow RAM [YES]	Serial Ports [Enabled ] Addresses [Normal ] Parallel Port [Printer] Bidirection [YES]
Video/Speaker	Power	Timeouts
Mode [VGA] Monitor [LCD COLOR] Cursor Type [Line ] Speaker [ON ]	Management [ON ] Resume Mode [OFF] VRAM Timeout [Enabled ]	Suspend Mode [00] Minutes Standby Mode [00] Minutes Display [02] Minutes Hard Drive [ 01] Minutes
<ESC> Exit to DOS without saving setup		<CTRL-BRK> Reboot without saving
<F1> Help for option that cursor is on		<SPACE> Toggles options
<F2> Save setup and exit		<ARROW> Moves to next option

#### Using the Setup Utility:

The Setup program (Setup381) lets you change startup parameters, power-management parameters, and other system parameters that you use in MS-DOS. Use the commands at the bottom of the screen to easily select and change the parameters.

To run the Setup program, follow these steps:

1. Exit from any program you are currently in.
2. If you are not in Drive C, type: c: <ENTER>
3. Select the DOS directory by typing: cd \dos <ENTER>
4. At the MS-DOS prompt, type: Setup381 <ENTER>

The Setup program screen appears.

5. Use the up and down arrows to select the parameter you want, and press the spacebar to choose the setting.
6. Press F2 if you want to save your changes. If you do not want to save the changes, press <ESC>.

The SETUP381 program lets you select system and power parameters, and store the parameters you select in memory. The computer uses these parameters you select in memory. The computer uses these parameters each time you start it up. Whenever you use the SETUP381 Utility, you must restart the computer to initialize the new parameters.

The SETUP381 parameters are arranged in the following groups:

- \* DATE AND TIME--These parameters allow you to set the DOS date and time.
- \* STARTUP--These parameters allow you to choose some of the internal settings that activate when you turn on your computer. You can use this group of parameters to select the initial program to run, the computer's speed (fast or slow), and the Shadow RAM.
- \* COMMUNICATIONS--These parameters allow you to turn the serial ports on

and off, and to set the parallel port to operate with an external printer or diskette drive.

- \* VIDEO/SPEAKER--These parameters allow you to select the type of video monitor emulation and the type of cursor you want to use with your computer. You can also turn the computer's speaker on and off.
- \* POWER--These parameters allow you to turn some of the computer's power saving options on and off, such as the computer's low-power management parameter, the floppy disk standby parameter, and the Resume mode. You can also turn on and off the VRAM Timeout feature.
- \* TIMEOUTS--These parameters allow you to save additional battery power by instructing the computer to automatically turn the display or hard drive off if you are not using the computer for a specified period of time.

(jej-05/10/94)