

# Composite to USB Capture Cable

## Installation Guide

---

This guide contains installation instructions for the following operating systems:

1. [Windows \(EXE\)](#)
2. [Windows \(INF\)](#)

# Composite to USB Capture Cable

## Installation for Windows (EXE)

### Install Guide

#### To install the driver:

1. Right-click the zip folder that you downloaded, click **Extract All**, and complete the instructions. The extracted files should open automatically.
2. In the list of extracted files, right-click the **setup.exe** file and click **Run as Administrator**.
3. Complete the instructions to install the device drivers.
4. Press the **Windows** key + **R**, type **devmgmt.msc**, and click **OK** to open the Device Manager.
5. Expand the **Sound, video and game controllers** section and confirm that **USB 2861 Device** is listed.

# Composite to USB Capture Cable

## Installation for Windows (INF)

### Install Guide

#### To install the driver:

1. Right-click the zip folder that you downloaded, click **Extract All**, and complete the instructions.

2. Press the **Windows** key + **R**, type **devmgmt.msc**, and press **Enter** to open the Device Manager.

3. Right-click the device that has "!" next to it, and click **Update Driver**.

**Note:** If the driver is being recognized properly but there is still an error with it, it will be listed as **USB EMP Audio Device**.

4. Click **Browse my computer for driver software**.

5. Select the **Let me pick from a list of device drivers on my computer** option.

6. If a list of hardware types appears, leave the **Show All** option selected, and click **Next**.

7. Select the **Have Disk** option.

8. Browse to the extracted folder, open the **Windows** folder, the **Twain Driver** folder, and the **Manual Driver** folder.

9. Open the **32-bit** or the **64-bit** folder, depending on your system type.

**Note:** To view your system type, click **Start**. Right-click **Computer**, and then click **Properties**.

10. Click the **EMAUDIO** (32-bit) file or the **EMAUDIO64** (64-bit) file. Click **OK**, and then click **Next**.

# Composite to USB Capture Cable

## Installation for Windows (INF)

### Install Guide

#### To install the driver:

To install the video drivers, complete the following:

1. Right-click the device that has “!” next to it, and click **Update Driver**.

**Note:** If the driver is being recognized properly but there is still an error with it, it will be listed as **USB 2861 Device**.

2. Click **Browse my computer for driver software**.

3. Select the **Let me pick from a list of device drivers on my computer** option.

4. If a list of hardware types appears, leave the **Show All** option selected, and click **Next**.

5. Select the **Have Disk** option.

6. Browse to the extracted folder, open the **Windows** folder, the **Twain Driver** folder, and the **Manual Driver** folder.

7. Open the **32-bit** or the **64-bit** folder, depending on your system type.

**Note:** To view your system type, click **Start**. Right-click **Computer**, and then click **Properties**.

8. Click the **EMVIDEO** file. Click **OK**, and then click **Next**.

If you are in North America, make sure that the Video Format is set to **NTSC-M** in the video capture software options. Also, make sure that you have the Video format set to capture from **S-Video** or **Composite**, depending on which you want to use.